

## Input module service

The Xsdot input module enables the connection of hardware input switches on a server. This module is used by the Alarm manager to connect external switches with alarm devices. This module is also used for general input switching functionalities.

